

# G-FLOOR

Floor Cover/Protector®

# Installation Sheet

## PRE-INSTALLATION

Measure floor to order proper amount of flooring.



Before ordering, measure the floor.



Clean floor before applying flooring

## INSTALLATION

**Step 1—Clean Floor.** Make sure garage floor is clean, dry, and free of any objects. Sweep dirt out of garage and remove any lumps or excess cement/debris that might cause a bump on the surface.

**Step 2—Unroll Floor.** Position G-Floor® at front of garage, one roll at a time. Roll flooring out—front-to-back—and position carefully.

Use a broom to push out any air underneath G-Floor.



Roll out flooring front-to-back



Push out any air with a broom

**Step 3—Joints & Cuts.** When installing multiple rolls wall-to-wall, dealers can:

a. **Overlap** rolls (1½" to 6")

— OR —

b. **Butt Joints** Trim edges to continue floor pattern by forming a tight butt joint between rolls. Follow guidelines for butt-type joints.



Overlap joint



Butt joint

**Butt-type seaming guidelines.** Fold back edge of roll #1 and wipe clean. Attach tape along roll #1's edge (leaving 2" of tape exposed) and fold back into position as shown.



**Butt-type seaming guidelines (continued).** Fold back roll #2 and wipe bottom edge clean. Carefully align along edge of roll #1. Do not stretch mat or tape when applying



Let G-Floor "float" between exterior walls to allow for expansion and contraction.



**NOTE:** For custom fit, always allow product to relax in place before trimming around edges and corners.

**Step 4—Trim.** Trim floor to fit around poles, boards, etc. using utility/rug knife or scissors. Trim edges along exterior walls leaving 1/4" gap to allow for expansion/contraction.



Trim carefully around edges leaving 1/4" gap

**Optional—Taping.** After product has been allowed to relax in place, if you choose to hold down edges or seams between two floor protectors, we recommend using indoor-outdoor carpet tape or 3-M® brand 80 Rubber & Vinyl Spray Adhesive.



For optional taping of front edge use 2-sided tape or 3M® brand 80 Rubber & Vinyl Spray Adhesive



**COMPLETED INSTALLATION**

